

UNIVERSAL REMOTE

Best position for duplication



Auto-scan Type

Multi-frequency

Up to 4 different remotes in 1

PROGRAMMING:

-standard

1. Hold button 1 and press button 2 four times, then release both buttons, the led of universal remote emits a quick flash every 2 sec.

2. Place and press the original remote control in front of the universal remote, at about 2-3 cm of distance, until the led of universal remote starts flash quickly.

3. While the LED of universal remote is flashing, press the button of the universal remote where you want to store, the remote code just copied, until the led will turn off.

Note:

To duplicate a second button, repeat the operation from the point 1.

Automatic matching code:

Hold on pressing press the button you want to match code, until the receiver emit the code, the led of the remote flash quickly, then release the button, the remote's code has matched successfully.

Emitting seed code:

Pressing the button 1 and button 2 at the same time until LED flashes quickly. Release two buttons, press the button that you want to emit seed code, it has emitted seed code successfully.

-BFT

1. Hold button 1 and press button 2 four times, then release both buttons, the led of universal remote emits a quick flash every 2 sec.

2. Place the original remote control in front of the remote, at about 2-3 cm of distance.

3. Press and retain pressed the button of the original remote control that you want to copy until the remote's led will turn on with a fix light and then emits a double flash every 2 sec.

4. Transmit now the seed code of the original remote control (by pressing the rear hide button or the buttons 1 and 2 simultaneously in the new models).

5. Now the LED will flash quickly, press the button of the remote where you want to store the code just copied, until the LED will turn off.

6. Now activate the **AMC** procedure to insert the new remote control on the receiver.

FAAC and GENIUS

ATTENTION, PLEASE: Verify that the remote control to be copied is a MASTER.

Pressing any button, the LED should issue a double flash rather than switch on immediately as a fixed light.

1. Hold button 1 and press button 2 four times.

2. Place the original remote control in front of the remote, at about 2-3 cm of distance.

3. Press and retain pressed the original remote control button that you want to copy until the LED universal remote switches on a fixed light and then it starts to emit a double flash every 2 seconds.

4. Predispose the FAAC/GENIUS remote control for the emission of the seed code (by pressing simultaneously the buttons 2 and 3).

5. While the FAAC/GENIUS LED is flashing, place it in front of the universal remote at about 2-3 cm of distance and press the button that you want to copy until the remote's led will change frequency of flashing (faster than before), as confirm of the correct copy of the code.

-V2

1. Hold button 1 and press button 2 four times, then release both buttons, the led of universal remote emits a quick flash every 2 sec.

2. Place the original remote control in front of the remote, at about 2-3 cm of distance.

3. Press and retain pressed the button of the original remote control that you want to copy until the remote's led will turn on with a fix light and then emits a double flash every 2 sec.

4. Press and retain pressed once again the same button of the original remote control.

6. Now the LED will flash quickly, press the button of the remote where you want to store the code just copied, until the LED will turn off.

5. Now activate the **AMC** procedure to insert the new remote control on the receiver.

COMPATIBILITES LIST

ACM	TX2, TX2 COLOR, TX4
ADYX	TE4E3N BLUE, 433-HSBRAND
AERF	COMPACT, HY-CDM, MERCURIB, MERCURIC, SABUTON, MARS SATURN, STAN, TERRA, TM-1, TM2, UNITECH
ALLMATIC	BROWN, BROWN RED, BRO. OVER, PASS, MINIPASS, TECH3
APERIO	GO, GO PRO, GO MINI
APERTO	TX02-434-2, TX02-888-2 BLUE, 4025 TX02-888-2, 4022 TX02-434-2, 4020, TX03-434, TX-50-888-4, 4013, TX03-434-4
APRIMAT C	TR2TR4, TM4, TXM
ATA	PTX4BLUE, PTX4PINK
AVDISEN	104251, 104250, 104250 OLD, 104250 RED, 104257, 104350, 654250
BALLAN	FM400, FM400E, FM404B, 4013
BENNIC	TO, GO, WY, TW, ROLLKEY, APPLE, LOT WVC, DUPIDO, TO, GO, OV, KI, LOT2WCV, LOT7W, LOT2WV, OT4W, OT7W, MLL, LOT2WV, TW, T4W, APPLE
BESIDE	BEZAPHIT
BFT	MITTO, MITTO M (MITTO), MITTO, MITTO RCB, MITTO RCB2, RCB4, MITTO A, MITTO 2, MITTO 4A, MITTO B, TRC1, TRC2, TRC4, GHBL, MURALE, KLEIO, TE01, TE02, TE04, RB4
CAME	MURALE
CAME	T431, T434, TOP432A, TOP434, TOP432, TAM432SA, TOP432NA
CARDIN	TRQ S449 (TRQ449), TRQ449, TRQ44900, TRQ449000, TRQ4490000, TRQ S449 GREEN (PRECODE), TXQ S449 (TXQ449000), TRQ S449 (TXQ4490000), TXQ S449 (TXQ44900000), TXQ S449 (TXQ449000000), S437 TX, XQ430, S449, S478, TX2, S478, TX2, S488, CASALI
CASALI	JAS3 AMIGD, GENIUS CASALI A252RC

AMC: Automatic matching code

CASIT	ERTS02B, ERTS92T, ERTS479D, ERTS20DQ, ERTS479D, ERTS479Q	KBLUE	ETH-TEL01	PROEM	ER4C4ACS
CELISA	S10 1, S10 2	KEY	800TXB-4R, SUB44, TXB-44R, TXQ-44R	PROGET	ETY_43N2, ETY_43N4
CENTURION	CLASSIC, SMART	KING GATES	STYLO, CLIPPER	PROTECO	TX433, EUROMATIC
CHAMBERLANULI	955E9T03271, LM, 971 LM, 84300E, 84304CE, 84320E, 84324E, 84335E, 8747E, 14539-1, 14547, 14647, 1328232	KLING	KUA, KUA E, KUA S	PLUOL	MARTE, P215, TWIN, VARIO, VARIO MARS, VARIO OCEAN, NEO
FT MASTER / MOTOR LIFT	84330EM, 84335EM, 84335EM, 84335EM, 84335EM, 84335EM, 84335EM, 8747EM	LABEL	SPYCO, RAVE	QUASAR	433
CLEMSA	MUTANCODE, T1-8 E-CODE N, MASTER CODE MV	LEB	TMW	RIB	LITHO
CPS	TCPS, CP51, TPC3, CP52, TPC3, CP54, TPC3	LINC	LR2035	ROPER	NEO, GO ROPER, GO MINI ROPER
DASPI	HAPPY2, POPS 2, ZERO RC1, ZERO 2RC, ZERO 4RC1	LIFE	FIDO	SABUTOM	BROOVER, BROSTAR
DEA SYSTEM	TRMIO, 133 1, 433 2, 433 4, GENIE, PUNTO S2, PUNTO 278, GOLDR, GENIE R 273, GENIE R-GT2N	LINEAR	MCT-11, ACT-21, ACT-22, STING RAY ACT-31, STING RAY ACT-34B	SEA	SMART DIP
DELMA	MIXARD 433 1, MIXARD 433 2, KING 433 2	MHOUSE	TX4	SEAV	BE HAPPY RS/BE-HAPPY-RS1, BE-HAPPY-RS2/BE-HAPPY-RS3, BE-SMART RSX, BE-HAPPY RH1, BE-HAPPY RH2, BE-HAPPY RH3
DICKERT	MAHS433 01, MAHS433 04	MA	TX1, TX2, TX3	SECULUX	NEO
DITEC	AMC GOL, GOL4C, BIXL2, BIXL2, BIXA64, BIXL6	MARATEC	D101, D12, DIGITAL, 302, DIGITAL304	SILVELOX	Mhz 2007, QUARZ SAW
DOTRABID	MPSTFZE, JAUNE	MERLINPROLIF T	M230T (PROLIFT), M430R (PROLIFT)	SIDE	4780207
DOORMATIC	SW	MERLINZ	E945M, E943M, E940M	SIMNOR	CVNXL, MITTO, SIM433
DOORHAN	TRANSMITTER 4	MHOUSE	TX4, TX3, GTX4	SECURVERA	SV R2C, SV R4C, SV R6C
DUCATI	TSAW1, TSAW2, TSAW3, 124, TE2	MOVVO	MT4G	SERAI	OGS2, OGS4, OGS8, OGS8A, OGS28, OGS48, OGS8, OGS4
ECOSTAR	RSE, RSC, RSZ	MONSEIGNEUR	ARC	SIMINOR	S433T-4T, ER2C4ACS, ER4C4ACS
ELBE	501, 502, 504, 500A, 504A	NICE	SMILO, FLOR-S, VERY-VR, INTFL02, FLO4, FLOR-S ERA, ONE (ON), ON ERA, ERGO, PLANO, ONE (ON FM)	SOMFY	TELIS, K-EASY, K-EASY NEW, K-EASY OLD, MITTO, KEY GO RTS, TELIS RTS, KEYTIS RTS, KEYTIS RTS NS, ALARMA
ERREKA	IRIS, ROLLER 2, ROLLER 433, NULLER 888, 50033, 50L888, VEGA 433, VEGA 888	NORTON	NEO, TXCD, GO NORTON, GO MINI NORTON	SOMMER	4010, 4011, 4014, TX03-434-2, 4013, TX03-434-4, 4020, TX03-888-4, 4026, TX03-888-2, 4022, TX02-434-2, 4025, TX02-888-2, 4031, TX08-888-4
ELBE	501, 502, 504, 500A, 504A	NOVOTECONCA	BIXL2	STAGNOLI	KALLISTO, VENUS AV223
ELCA	IRIS, ASTER 2, ASTER 1000, ASTER 1001	NOVOTRON	NOVOTRON 502-504-S (MIX), 2, MTRB-2, MCHS42-2, MHS432, 4, MHS432-2, 4, MHS, MINI-NOVOTRON 504, MICRO-NOVOTRON 502, MICRO-NOVOTRON 504, MICRO-NOVOTRON 31, MICRO-NOVOTRON 51, MINI-NOVOTRON 30, MINI-NOVOTRON 50, MNHS	TAU	250K-SLMRP, 250K-SLMR, 250T-4RP
FAAC	AMC RX4 433 RC, TM1 433 DS, TM2 433 DS, TM3 433 DS, 433L2, 433L4, TM22 433 SLP, TM4 433 SLP, TM4 433SL, TM4 888 SLH, 01, 888 SLH, XT 888SLH, XT 433 SLH, T 433 SLH, XT 433 RC, TE433H	NOLOGO	ECO DIP	TELCOMA	FM 402, FM 402 E, FM400E, FM400
FADIN	AMC LUB-SMALL, 433M2, ASTRO 433-2, ASTRO 433-4, JUB2, JUB4	NORMSTAHL	T433	TOR LIFT	TORMIT4
FERPORT	TAC1, TAC2, TAC4, TAC 1K, TAC 2K, TAC 4K, TAC2KR	O & O	T, COM, TWIN, TX, TWIN, TX2, TX4, NEO, T, COM R4-2T, COM R4-4, T, COM R8-2T, COM R8-4	VDS	TRQ P, ECO-R
GIBIDI	OPEN TMB, OPEN OUT, AU1600, AU1600 WOOD, AU1680, AU1680 WOOD, DOMINO	OG	OG62, OG64	VRAWFORD	EA433 4K, SMART2, SMART3
GULLLIVER	MDW	OPENOUT	TMQ	V2	PHOENIX 433-888, TXC, TSC, TRC, HANDY, SERIE ROYAL, TRR43, TRR243, TRR443, PHOX 433
GENIUS	AMIGD, AMIGOLD, XILD, BRAVO, ECHO	PECCININ	TX MENBRANA	AMC	
GENIE	GTR-3, GIT, GICT360, GIFT360-1, G3T-BX, G1T-BX, GMT, GICTD, GIFTD	PORTAMATIC	MPH01, MPH02		
GIBIDI	AU1680, AU1680, COM-NO AU1680 WOOD, GIBIDI AU1610, AU1610, AU1610, AU1610, DTC 433A	PRASTEL	TC2E(4E), SLIM, BFOR, MPSTP2E, MPSTF2, MPSTF4, MPSTF2RE, MPSTF4RE, MPSTP2E, MPSTP2E BLUE, MTEIMTAE, MTZEL, TRQ P (TRQ4P, TRQ2P), MPSTLE, MPSTL-1E, MPSTL-2E, MPSTL-4E		
HORMANN	HSM2, HSM4				
JCM	NEO, TWIN, GO, GO PORTIS, GO NORTON				
JAY	UBE1, X1SL1, LBET 11, LBET 21, LBET 31, LBET 41, LBET 51				